



POSITIVE OUTPUT WHEN THE LOADING IS APPLIED TO THE TOOL SIDE OF THE LAODCELL, PER COORDINATE SYSTEM AS SHOWN

CHANNELS ARE COUPLED, AND DECOUPLED MATRIX ARE PROVIDED

SPECIFICATIONS	
EXCITATION MAX. (V)	7
OVERLOAD CAPACITY (%F.S.)	200
CROSSTALK (%F.S.)	2.5
NON-LINEARITY (%F.S.)	0.5
HYSTERESIS (%F.S.)	0.5
OPERATING TEMP. RANGE (°C)	-40 TO +90
COMPENSATED TEMP. RANGE (°C)	10 TO 70
MASS (KG)	0.1

	Fx	Fy	Fz	Mx	My	Mz
CAPACITY (N/Nm)	200.0	200.0	200.0	30.0	30.0	30.0
OUTPUT (mV/V)	COUPLED OUTPUT					
BRIDGE RES. (Ω)	1400	1400	1400	1400	1400	1400

WIRING CODE - TWISTED PAIR						
FUNC	CHN1	CHN2	CHN3	CHN4	CHN5	CHN6
+SIG	WHITE (BROWN)	ORG (BROWN)	BLUE (BROWN)	YEL (BROWN)	RED (BROWN)	WHITE (BLACK)
-SIG	BROWN (WHITE)	BROWN (ORG)	BROWN (BLUE)	BROWN (YEL)	BROWN (RED)	BLACK (WHITE)
+EXC	RED (BLACK)					
-EXC	BLACK (RED)					
"YEL"="YELLOW", "ORG"="ORANGE", "WHITE (BROWN)" = WHITE CABLE IN WHITE/BROWN PAIR						

SUNRISE INSTRUMENTS
www.srisensor.com

SIX AXIS CIRCULAR LOAD CELL
 COUPLED, D35MM F500N

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN MM	M4312K3	REV. A
--	---------	-----------